

DH24 Humidity control.

Operation of the display.

When the control is properly electrically connected to the display:

Relative humidity: Hum: %

Temperature: Temp: °C

Dew Point: Dew: °C



To set or verify settings:

1: Touch "SET" for about 7 seconds. (This represents the simultaneous "child lock")

Display shows: **Hum Start** % RH - dehumidifier starts at this value.

Changing the value by using arrow up or down.

Ex adjust to value 60% RH.

2: Press "SET":

Display shows: **Hum Stop** % RH - dehumidifier stops at this value.

Changing the value by using arrow up or down.

Ex adjust to value 58% RH (must be lower than Hum Start)

3: Press "SET":

Display shows: **Dew start** °C - dehumidifier starts at this value.

Changing the value by using arrow up or down.

Ex adjust to value 0°C dew point. If target is no controlled dew point, set value = 30°C.

4 Press "SET":

Display shows: **Dew Stop** °C - dehumidifier stops at this value.

Changing the value by using arrow up or down.

Ex adjust to value -2°C. (must be lower than the Dew Start). If target is no controlled dew point, set 29°C.

5 Press "SET":

Display shows: **Hum Alarm** % RH - alarm starts at this value.

Changing the value by using arrow up or down.

Ex adjust to value 65% RH.

6 Press "SET":

Display shows: **Dew Alarm °C** - alarm starts at this value.

Changing the value by using arrow up or down.

Ex set 2°C. If target is no controlled dew point, set 40°C

7 Press "SET":

Display shows: **Alarm Repeat min.** - the alarm is repeated at that time.

Changing the value by using arrow up or down.

Ex set 30 minutes. The alarm functioning both set% R and set dew point.

The alarm sounds in the control panel.

The alarm can be reset as follows:

press "SET" and the noise is silenced.

Alternatively, the time is set down "No Repeat".

8 Press "SET":

The display now shows: **Set Clock.** This is set to the correct time using the arrow up and down.

9 Press "SET":

The display now shows: **Set Date.** Date set to the correct date indication.

10 Press "SET":

The display now shows: **Set Month.** Month name set.

11 Press "SET":

The display now shows: **Set year.** Year set.

12 Press "SET":

Display shows: **Factory set.** Appears NO and if factory setting is desired, press one of the arrows for 10 seconds (can be followed in the display) and the default setting is now set.

ON / OFF:

Changes the display between **Day / date / time** and display of **humidity and temperature**.